



ANTENNA DISCONNECTION PROCEDURE

Related product: XT, XV, XT-IP, XV-IP and XTO panels

This procedure will help you detach the panel's internal GPRS antenna without damaging or tearing the welded connectors of the electronic board.

1 – Gently push the coaxial cable in order to slightly tilt forward the connector.



2 – Please use a large standard (flat) screwdriver, and place under the horizontal and rigid end of the connector.



3 – Turn the screwdriver to lift and unclip the coaxial connector, then clip on your external GPRS antenna in order to boost your reception.



VDT Direct LTD

**6A Hazel Court, Burma Road Industrial Estate, Blidworth, Nottinghamshire, NG21 0RY, United Kingdom ●
Tel: +44-115-714-9990 ● Fax: +44-1623-490958 ● www.vdomain.co.uk**