

Videofied uses the MB601 Panavise mount with almost every Outdoor MotionViewer installation. In some situations you may need/want to use the MB601 with an Indoor MotionViewer (IMV). As there is not a thread included with the IMV this document will explain a way to modify the IMV to use the MB601.

Required Parts and Tools:

1 - MB601 Mounting Bracket

1 - Indoor MotionViewer

1 - 1/4" x 20 nut

1/4" drill bit and drill


A unit of quick dry adhesive (optional/recommended)



1. Take of the back of the Indoor MotionViewer off and mark the location where you will be drilling the hole. For the nut to fit inside of the casing you must use the mounting point in the picture below. Drill out the hole with the 1/4" drill bit.



2. Apply a layer of the adhesive (optional/recommended) to the interior of the cover on the outer ring of the hole you just drilled and place the nut so that it lines up with the hole.



IMV Mounting Bracket Modification

3. If used, allow the adhesive to dry a little bit but not all the way. Screw in the MB601 and use the bracket to pull the nut tight to the back of the case. Fill around the nut with more adhesive, avoid the inside of the nut, and allow to dry according to the instructions on the adhesive.



EMEA SALES

23, avenue du Général Leclerc
92340 BOURG-LA-REINE
FRANCE
Hotline: +33 (0)820 846 620
Fax: +33 (0)1 82 69 80 10

USA SALES

1375 Willow Lake Blvd. #103
Vadnais Heights, MN 55110
USA
Hotline: +1 877 206 5800
Fax: +1 651 762 4693

www.videofied.com

© 2011 RSI VIDEO TECHNOLOGIES. VIDEOFIED® is a Registered Trademark of RSI VIDEO TECHNOLOGIES.
S'View® is a registered trademark of RSI VIDEO TECHNOLOGIES. Specifications subject to change without notice.